



## Turnbuckle Kits, Options CK12-CK40 for VISION Heater Models VPS, VPT, VCS, VCT

### Description/ Application

For proper operation and safety, tubular radiant heaters must be suspended by chain and must be installed and maintained in a level position. To facilitate leveling, turnbuckles are recommended.


Turnbuckle option kits come in packages of four to twelve turnbuckles so that the quantity matches the number of heater suspension points. The number of suspension points varies by Model and Size.

### Location and Quantity of Suspension Points by Model

Model	Burner/ Control Box	Combustion Chamber Tube	Heat Exchanger Tube			
			Each of 5 or 10 ft Straight (except downstream adjacent to "U" or "L")	Each of 5 or 10 ft Straight downstream adjacent to "U" or "L"	"U"	"L"
VPS	2	1	1	2	0	0
VPT						
VCS						
VCT						

### Components

(Qty per pkg is the number of turnbuckles and nuts in each kit.)



Model	Straight Length (feet)	System Configuration					
		Option No.	Package P/N	Qty per pkg	Option No.	Package P/N	Qty per pkg
		Straight			With one "L" or "U"		
Standard VPS VPT	20	CK12	270697	4	CK13	270698	5
	30	CK13	270698	5	CK14	270699	6
	40	CK14	270699	6	CK15	270700	7
	50	CK15	270700	7	CK16	270701	8
	60	CK16	270701	8	CK17	270702	9
	70	CK17	270702	9	CK18	270703	10
	80	CK18	270703	10	CK28	270733	11
	90	CK28	270733	11	CK29	270734	12
Stainless Steel VCS VCT	20	CK32	270704	4	CK33	270705	5
	30	CK33	270705	5	CK34	270706	6
	40	CK34	270706	6	CK35	270707	7
	50	CK35	270707	7	CK36	270708	8
	60	CK36	270708	8	CK37	270709	9
	70	CK37	270709	9	CK38	270710	10
	80	CK38	270710	10	CK39	270735	11
	90	CK39	270735	11	CK40	270736	12

### Chain Options:

**Option CK 11 - P/N 270725:** 50 foot of Chain & (11) S-Hooks.

**Option CK 31 - P/N 270717:** 50 foot of Stainless Steel Chain & (11) S-Hooks.

### Preparation and Installation Instructions

#### WARNING

The kit is to be installed by a qualified service person in accordance with these instructions and in compliance with all codes and requirements of authorities having jurisdiction. The qualified agency performing this work assumes responsibility for this installation.

#### Assemble the Turnbuckle and Locking Nut

Remove the eyebolt with the right-hand thread. With the "teeth" of the nut away from the "eye" end of the bolt, screw the nut onto the bolt until the nut is close to the eye.



[www.ReznorHVAC.com](http://www.ReznorHVAC.com); (800)695-1901

©2015 Reznor LLC. All rights reserved.

All other trade marks are the property of their respective organizations.